

/LED MIRROR

INSTALLATION & USER INSTRUCTIONS

IMPORTANT

All goods must be checked prior to installation. If defects are found due to manufacturing faults then goods **MUST NOT** be installed.

ALL LED MIRRORS MUST BE:

- Installed by a qualified electrician.
- Connected to an isolation switch.
- Switched off at isolation switch when not in use.
- Not left on for prolonged periods.

Operating Instructions

Single Button Mirrors

How to Turn Mirror Light On/OFF

To turn the LED mirror on, press the on/off sensor button located on the face of the mirror. To turn off, push sensor button once more.

How to Use the Dimming Function

Turn the mirror on by pressing the button. Once the mirror is on, hold your finger on the button to dim. Release button once the desired brightness level is reached. To increase brightness, hold finger on the button again, and release at the desired brightness.

Demister Function

The demister function will automatically turn on when the mirror is illuminated.

Double Button Mirrors

How to Turn Mirror Light On/OFF

Turn on the LED mirror by pressing the on/off sensor button on its face; the button will glow blue. To turn it off, press the sensor button again, and the button will glow white.

How to Use the Dimming Function

Once the mirror is on, hold your finger on the button to dim. Release button once the desired brightness level is reached. To increase brightness, hold finger on the button again, and release at the desired brightness.

Demister Function

Press the demister button on the mirror's face to turn on the function; it will glow blue. Press the button again to turn it off, and when off, the button will glow white.

Troubleshooting

Mirror not turning on

It is possible to dim the mirror so much that the mirror will not turn on. The mirror needs to be reset. Switch off at the wall for 10-20 seconds, and then on again.

Other issues with the switch

- Check sensor button is clean.
- The switch can take some getting used to with pressure and time applied to switch on and off.

Please check the mirror is operating correctly before removing the plug and wiring directly into the wall.