

/ SHOWER TRAYS & WALL LINERS

INSTALLATION INSTRUCTIONS

IMPORTANT

All goods must be checked prior to installation. If defects are found due to manufacturing faults then goods MUST NOT be installed.

The manufacturer will not be liable for any installation, removal or re-decorating costs. The warranty will be null and void if damage occurs during or after installation. If there is a proven manufacturing defect i.e. outside of tolerance and the installation is carried out then, the manufacturer will replace the item. However, the installation costs will be the responsibility of the installer.



IMPORTANT

It is recommended that a qualified, licensed trades person install your tray.

Contents

[pg 2 Shower Tray Installation](#)

[pg 4 Product Care](#)

[pg 5 Wall Liner Installation](#)

[pg 6 Trouble Shooting](#)

[pg 7 Warranty Terms & Conditions](#)

/ SHOWER TRAY INSTALLATION

Required Tools & Materials



Spirit level



Master gun



Drill & bits



Tape measure



Sharp knife



Adhesive
Sika Showerbond



Levelling compound
(If required)

01

Inspect The Tray

Prior to installation it is important to inspect the tray to ensure no damage has occurred in transit. If damage has occurred, or a visible defect exists, do not proceed with installation and advise supplier immediately. **Note: Manufacturer will not be liable for any installation, removal or re-decorating costs. The warranty will be null and void if damage occurred during or after installation.**



IMPORTANT


DO NOT Gib stop, sand, seal or paint the wallboard surface as this will affect the adhesion of the acrylic wall liner.

02

Check The Walls & Floor Is Straight

Ensure that the walls are plumb and square. Check the floor area is level and the waste is in the correct position. Place tray on the area concerned and check levels again.


It is the Installers responsibility to make sure that the tray is level on all four sides. Failure to do so will compromise the installation of the liner and the shower enclosure. Use floor levelling compound as and when required or in the case of a wooden floor, plane the area flat and level, as an uneven surface will cause stress upon the acrylic skin and this can lead to de-lamination or cause the shower tray to creak.



03

Check Tray Position


Check the position of the tray on the level surface – shower trays that are fitted with our factory fitted upstands need to be installed in accordance with our requirements to pack the bottom wall plate up to 6mm to accommodate this. If a tiling strip is being used the tray is installed after the wall lining. **See page 5.**



04

Check & Prepare Waste Position

Once the waste position has been set up you will need to backfill any hole with concrete and depending upon the size of the hole allow this to dry overnight before you attempt to glue the tray to the floor. **If the floor is damp the glue will not adhere to the surface properly and this is easily recognised if any warranty is actioned in the future.**



! IMPORTANT


Hole cut out for waste must not exceed 170mm square.

Concrete Floors must be back filled around the waste area particularly where any additional cuts in the concrete. (Use concrete or a similar solid fill material).

05

Prepare the Tray


Remove the protective film from around the outside edge and centre and apply the adhesive onto the back of the tray ensuring good even coverage to gain maximum adhesion over a large surface area. Thin lines or small blobs will not create the adhesion to the floor that is required and this may lead to the tray creaking when moving around inside the enclosure.



06

Position Tray & Connect Waste


Turn the tray over, place into final position and tighten up the Easiclean waste.



07

Set the Tray in Place

Use the packaging to cut a protective cover for the shower tray and then place bags of Mortamix or similar on the tray to ensure an even spread of weight whilst the adhesive cures. **Leave overnight as a minimum before installing the shower doors and wall linings.**



NOTE: The walls and upstand area will require a waterproof membrane if tiles are to be installed.

/ PRODUCT CARE

Providing the shower tray has been correctly installed, difficulties should not be encountered. If any maintenance is required then it must be carried out by a qualified Plumber or Engineer.

It is advised that the shower tray is cleaned regularly, to remove any insoluble products. Hot soapy water should be used and then the tray


should be wiped. Cleaners of gritty or abrasive nature should not be used.

The acrylic surface of this shower tray has good resistance properties to acids but should not come into contact with alkalis or organic solvents, such as caustic soda, dry cleaning agents and paint strippers.


/ WALL LINER INSTALLATION

Wall Liner with Factory Fitted Upstand Installation

Acrylic Wall Liner




Tiled Wall




Wall Liner with Moulded Upstand Installation

Acrylic Wall Liner



Tiled Wall



/ TROUBLE SHOOTING & COMMON QUESTIONS

Problem	Solution
My product is damaged, should I install it?	No , please contact the merchant you purchased your product from immediately
Where can I find the dimensions and specifications?	Our specifications are found on our product pages on our website www.bathco.co.nz
What should I clean my product with?	View our Product Care info on page 4 or download our comprehensive guide from our website www.bathco.co.nz/downloads/product-info-installation
What happens if I need spare parts?	Please contact the merchant you purchased your product from
Does it come with a warranty?	Yes, please view our warranties information on page 7 or online www.bathco.co.nz/warranties
How long is my warranty for?	Our warranties differ please view our warranties information online www.bathco.co.nz/warranties
How do I make a warranty claim?	Please contact the merchant your purchased from.

/ WARRANTIES

Residential Warranty Periods



Shower Hoses
Shower Heads
Cartridges
Mirrors
Cistern Fittings
Wastes
Toilet Seats
Electrical
Face Plates
Washers
Valves
Shower Seals



Vanities & Cabinetry
Basins
Tops
Baths
Toilets
Showers & Shower Trays
Tapware



In-Wall Cisterns
(Excluding items listed previously)



Extended guarantees are available on Burlington products directly from the manufacturer, Bathrooms Brand Group (English Classic vanities and in-wall cisterns are not applicable).

Commercial Warranty Period

In relation to any Bath Co products installed in a commercial situation a 12 month warranty applies from the date of purchase. Commercial situations are defined as public washrooms, public buildings, schools, sports centres, gymnasium, hospitals, motels, hotels and retirement villages.

Terms & Conditions

Bath Co warranties apply to products supplied to customers in New Zealand. Subject to the warranty conditions, in addition to any other right or remedy that the purchaser may have under any relevant consumer protection legislation, Smail & Co undertakes to either repair or replace (at its discretion) any Bath Co product if that product contains a material defect with either materials or workmanship which arose in the course of manufacture.

Bath Co's domestic/residential warranty and commercial warranty is subject to the following conditions:

Proof of purchase (such as invoice or receipt) must be provided by the initial purchaser. This warranty is not transferable.

All Bath Co installation instructions must have been strictly followed and the product must have been installed in accordance with the relevant New Zealand Building/Plumbing Codes by a certified building or plumbing practitioner (as appropriate for the product).

The product must not have been subject to excessive

wear and tear. The warranty only covers normal use and typical wear and tear.

The product must not have been tampered with or repaired in any way other than in accordance with this warranty.

The product must not have been damaged by misuse, accident or neglect, including water damage, sunlight, excessive water temperature, humidity, direct lighting or other adverse environmental conditions.

Harsh detergents or abrasive cleaners must not have been used on the product and the product must be cleaned in accordance with the recommended

cleaning methods.

All warranty covered repair work is to be performed by Bath Co but Bath Co shall not be responsible for the cost of removal or installation of the product.

Bath Co shall make the final determination on any issue or uncertainty regarding the application of this warranty.

If you acquired the Bath Co product in trade (or some other exception exists under the Consumer Guarantees Act 1993 (the Act) then the Act shall not apply.

**BATH/
CO/**

**/SHOWER TRAY
& WALL LINER
INSTALLATION INSTRUCTIONS**

